

Additional User manual Scenesetter 24 and Scenesetter 48 How to patch DMX Channels

DMX Channel Assignment:

- Press *RECORD (FLASH8) (FLASH8) (FLASH8)*
- Select one of the 24/48 Channels with the *FLASH* button
- Set the DMX Channel with (*UP*) or (*DOWN*) between 1 – 512
- Press *RECORD+EXIT* to save setting and exit

DMX Channel Assignment Reset:

- Press *RECORD (FLASH7) (FLASH7) (FLASH7)*
- Press *RECORD+EXIT* to save setting and exit